



# STEP BY STEP

How to measure your door!

01

## Door Cuts

For a door cut, with no glass we need either 21" or 23 " width and either 65" or 81" tall.

02

## Swap Out Window Inserts

We measure Glass ONLY do not include frame and should get either 19" or 21" width and either 63" or 79" tall.

03

Call for more information: 941-921-5265

AND

Let there be light!

<https://brumartglass.com/>